

## Revolabs HD Single / Dual Channel System — LifeSize Room 200 Setup

---

This setup guide will guide you through the steps needed to properly connect a Revolabs HD Single or Dual Channel System to a LifeSize Room 200 video codec.

**Note:** *It is important to carefully follow these instructions in order and completely. Otherwise your Revolabs Microphone System and/or the video codec may not function properly. Please read through these instructions completely before proceeding. Contact Revolabs technical support if you have any questions.*

### **Requirements for connecting systems:**


1. Revolabs HD Single or Dual Channel System
2. LifeSize Room 200 video codec
3. QTY 1 3.5mm unbalanced male to 3.5mm unbalanced male cable\*

\* 07-35MUTO35MU-01 3.5mm unbalanced male to 3.5mm unbalanced male cable available from Revolabs

## Connecting the Cables

---

1. Insert the unbalanced 3.5mm male connector to the CH 1 OUT port on the Revolabs Single or Dual Channel System. If using a Single Channel, DIP Switch #1 should be "OFF". If using a Dual Channel, DIP Switch #1 should be "ON".
2. Insert the other 3.5mm male connector into the LifeSize Room 200 LINE IN.
3. Verify that DIP Switch #3 (mic/line) is "OFF"



## Configuring the LifeSize Room 200 Video Codec

1. Push the BLUE button on the remote control for SYSTEM MENU
2. Select ADMINISTRATOR PREFERENCES and enter password (if necessary)
3. Select AUDIO
4. Select LINE IN (AEC)
5. Adjust ACTIVE MICROPHONE VOLUME to 10