RALLY BAR
RALLY BAR MINI

WIRING DIAGRAMS

3 MARCH 2021


HDMI
HDMI
Ethernet
HDMI 1 out
USB A
Tap (optional)


HDMI
HDMI
Ethernet
HDMI 1 out
USB A
HDMI
Tap (optional)


HDMI
HDMI
Ethernet
HDMI 1 out
USB A
HDMI
Tap (optional)


HDMI
HDMI
Ethernet
HDMI 1 out
USB A
Tap (optional)



logitech

Rally Bar / Rally Bar Mini
Appliance Mode
Rally Bar max 3 mic pods; Rally Bar Mini max 2 mic pods



logitech

Rally Bar / Rally Bar Mini
Appliance Mode:
Rally Bar max 3 mic pucks; Rally Bar Mini max 2 mic pucks



Rally Bar / Rally Bar Mini
Appliance Mode: With Logitech Swytch


Swytch Hub
USB-A
A/V
HDMI
PC
USB-C
PC
HDMI
TV
USB-C
EXT
PC
HDMI
HDMI
Ethernet
USB C
Tap (optional)
Swytch Extender
USB



Rally Bar / Rally Bar Mini
USB Mode: Dual screens with Logitech Swytch


HDMI
USB
HDMI
Ethernet
USB C
HDMI in
HDMI 1 out



logitech

Rally Bar / Rally Bar Mini
BYOD Mode: Rally Bar up to 3 mic pods
Rally Bar Mini up to 2 mic pods



Rally Bar / Rally Bar Mini
BYOD Mode: Rally Bar maximum 2 mic pods when used with Mic Pod Hub
Rally Bar Mini maximum 1 mic pod when used with Mic Pod Hub


HDMI
HDMI
USB
HDMI
Ethernet
USB C
HDMI in
HDMI 1 out


HDMI
HDMI
PC
USB
USB C
Ethernet
Tap (optional)



logitech

Rally Bar / Rally Bar Mini
USB Mode: Rally Bar up to 3 mic pods
Rally Bar Mini up to 2 mic pods



Rally Bar / Rally Bar Mini
USB Mode: Rally Bar maximum 2 mic pods when used with Mic Pod Hub
Rally Bar Mini maximum 1 mic pod when used with Mic Pod Hub


HDMI
HDMI
PC
USB
USB C
Ethernet
HDMI
Tap (optional)


HDMI
HDMI
PC
USB
USB C
Ethernet
Tap (optional)


USB (Touch)
USB
Ethernet
USB C
USB A


HDMI
USB
Ethernet
USB A
HDMI 1 out