

Revolabs HD Single / Dual Channel System — Tandberg C20 Setup Guide

This setup guide will guide you through the steps needed to properly connect a Revolabs HD Single or Dual Channel System to a Tandberg C20 video codec.

Note: *It is important to carefully follow these instructions in order and completely. Otherwise your Revolabs Microphone System and/or the video codec may not function properly. Please read through these instructions completely before proceeding. Contact Revolabs technical support if you have any questions.*

Requirements for connecting systems:

1. Revolabs HD Single or Dual Channel System
2. Tandberg C20 video codec
3. QTY 1 3.5mm balanced male to 3.5mm TRRS cable*

* 07-35MBTO35M4-01 3.5mm balanced male to 3.5mm TRRS male cable available from Revolabs

Connecting the Cables

1. Insert the 3.5mm balanced male connector to the CH 1 OUT port on the Single or Dual Channel System. If using a Single Channel, DIP Switch #1 should be "OFF". If using a Dual Channel, DIP Switch #1 should be "ON".
2. Insert the 3.5mm TRRS male connector into the Tandberg MICROPHONE 1 port
3. Verify that DIP Switch #3 (mic/line) is "ON"

