

Revolabs HD Single / Dual Channel System — LifeSize Express Setup Guide

This setup guide will guide you through the steps needed to properly connect a Revolabs HD Single or Dual Channel System to a LifeSize Express video codec.

Note: *It is important to carefully follow these instructions in order and completely. Otherwise your Revolabs Microphone System and/or the video codec may not function properly. Please read through these instructions completely before proceeding. Contact Revolabs technical support if you have any questions.*

Requirements for connecting systems:

1. Revolabs HD Single or Dual Channel System
2. LifeSize Express video codec
3. QTY 1 3.5mm balanced male to 3.5mm balanced male cable (07-35MBTO35MB-01 provided with Revolabs Microphone System)

Connecting the Cables

1. Connect one end of the 3.5mm balanced male cable to the CH 1 OUT port on the Single or Dual Channel System. If using a Single Channel, DIP Switch #1 should be "OFF". If using a Dual Channel, DIP Switch #1 should be "ON".
2. Connect the other side of the 3.5mm balanced male cable into the LifeSize Express LINE IN
3. Verify that DIP Switch #3 (mic/line) is "OFF"



Configuring the LifeSize Express Video Codec

1. Push the BLUE button on the remote control for SYSTEM MENU
2. Select ADMINISTRATOR PREFERENCES and enter password (if necessary)
3. Select AUDIO
4. Select LINE IN (AEC)
5. Adjust ACTIVE MICROPHONE VOLUME to 10