

Revolabs HD Single / Dual Channel System — Polycom HDX 8000 Setup Guide

This setup guide will guide you through the steps needed to properly connect a Revolabs HD Single or Dual Channel System to a Polycom HDX 8000 video codec.

Note: *It is important to carefully follow these instructions in order and completely. Otherwise your Revolabs Microphone System and/or the video codec may not function properly. Please read through these instructions completely before proceeding. Contact Revolabs technical support if you have any questions.*


Requirements for connecting systems:

1. Revolabs HD Single or Dual Channel System
2. Polycom HDX 8000 video codec
3. QTY 1 3.5mm unbalanced male connector to dual RCA male connector cable*

* 07-35MUTODRCA-01 6' 3.5mm unbalanced male connector to dual RCA male connector cable available from Revolabs

Connecting the Cables

1. Insert the unbalanced 3.5mm male connector to the CH 1 OUT port on the Single or Dual Channel System. If using a Single Channel, DIP Switch #1 should be "OFF". If using a Dual Channel, DIP Switch #1 should be "ON".
2. Insert the dual RCA male connectors into the red and white AUDIO INPUT AUX ports.
3. Verify that DIP Switch #3 (mic/line) is "OFF"



Configuring the Polycom HDX 8000 Video Codec

1. Select SYSTEM
2. Select ADMIN SETTINGS and enter the Administrator password (if needed)
3. Select AUDIO
4. Select AUDIO SETTINGS
5. Disable POLYCOM MICROPHONES by removing the check mark. Having Revolabs and Polycom microphones may increase ambient noise, add to echo cancellation problems, and reduce articulation
6. Verify LIVE MUSIC MODE is disabled by removing the check mark. Polycom noise suppression is turned off when this is active
7. Select INPUTS/OUTPUTS
8. Confirm or modify the following settings:
 - INPUT TYPE is LINE INPUT
 - INPUT TYPE LEVEL is 50% or 5
 - ECHO CANCELLER is ON
9. Press OK to save all changes