

## Revolabs HD Single / Dual Channel System — Polycom QDX 6000 Setup

---

This setup guide will guide you through the steps needed to properly connect a Revolabs HD Single or Dual Channel System to a Polycom QDX 6000 video codec.

**Note:** *It is important to carefully follow these instructions in order and completely. Otherwise your Revolabs Microphone System and/or the video codec may not function properly. Please read through these instructions completely before proceeding. Contact Revolabs technical support if you have any questions.*

### **Requirements for connecting systems:**


1. Revolabs HD Single or Dual Channel System
2. Polycom QDX 6000 Video Conferencing System
3. QTY 1 3.5mm unbalanced male connector to dual RCA male connector cable\*

\* 07-35MUTODRCA-01 6' 3.5mm unbalanced male connector to dual RCA male connector cable available from Revolabs

## Connecting the Cables

---

1. Insert the unbalanced 3.5mm male connector to the CH 1 OUT port on the Single or Dual Channel System. If using a Single Channel, DIP Switch #1 should be "OFF". If using a Dual Channel, DIP Switch #1 should be "ON".
2. Insert the dual RCA male connectors into the red and white LINE IN ports.
3. Verify that DIP Switch #3 (mic/line) is "OFF"



## Configuring the Polycom QDX 6000 Video Codec

---

1. Push the HOME button to return to the MAIN MENU
2. Select SYSTEM
3. Select ADMIN SETTINGS
4. Select AUDIO
5. MIC GAIN is from -9 to +3. Start with "0" and raise/lower as needed
6. Turn ECHO CANCELLATION to ON